

# INSTALLATION INSTRUCTIONS 2007 JEEP WRANGLER JK PROTHANE 2" SUSPENSION LIFT SYSTEM 1-1708



Prothane recommends this and all polyurethane kits be installed by a trained professional.  
Please read complete instruction sheet before beginning any work.

- 1) Place front of vehicle on jack-stands to support chassis.
- 2) Place floor-jack under front axle and remove wheels, lower shock bolts, sway bar links, and brake hose brackets if necessary.
- 3) Loosen and leave in place the track bar and upper & lower trailing arm bolts. This will allow the front axle to pivot freely.
- 4) Lower the front axle and remove and discard the original rubber spring isolators and foam bump-stops.
- 5) Install Prothane 67069 bump-stop into cup on chassis.
- 6) Place Prothane 60773 coil spring spacer on top of coil spring and slowly raise front axle until the spacers begin to seat in the chassis. Reinstall bolts into lower end of shocks. Reconnect sway bar links.
- 7) With front end under compression retighten track bar and trailing arm bolts to 80ft/lbs.
- 8) Place rear of vehicle on jack-stands to support chassis.
- 9) Place floor-jack under rear axle and remove wheels, lower shock bolts, sway bar links and track bar. Unbolt brake line brackets if necessary.
- 10) Loosen and leave in place the upper & lower trailing arm bolts. This will allow the rear axle to pivot freely.
- 11) Lower the rear axle and remove & discard the original rubber spring isolator and foam bump-stops.
- 12) Place Prothane 60774 coil spring spacer on top of coil springs and raise axle until the spacers begin to seat in the chassis. Reinstall bolts into lower end of shocks. Reconnect sway bar links. Reinstall track bar. Reattach brake line brackets.
- 13) With rear end under compression retighten track arm and trailing arm bolts to 80ft/lbs.
- 14) Install wheels and place vehicle back on ground.

PART NO.	DESCRIPTION	QUANTITY
60773	2" FRONT COIL SPACER	2
60774	2" REAR COIL SPACER	2
67069	2" FRONT BUMP-STOP	2
67070	2" REAR BUMP-STOP	2
**FORM 1-1708	INSTALLATION INSTRUCTIONS	1

3560 CADILLAC AVENUE, COSTA MESA, CA 1-888-PROTHANE