

INSTALLATION INSTRUCTIONS FOR KITS #4-1605 & #4-1606 NEON & SRT-4 SHIFTER BUSHING KITS

PROTHANE™ RECOMMENDS THAT THIS KIT BE INSTALLED BY A QUALIFIED AUTOMOTIVE TECHNICIAN

- 1) REMOVE THE CONSOLE SURROUNDING THE SHIFTER.
- 2) GENTLY PRY THE CABLE ENDS OFF OF THE SHIFTER-TRANSMISSION LEVERS.
- 3) REMOVE THE FACTORY BUSHINGS BY PUSHING THEM OUT OF THE TOP WITH A SCREWDRIVER OR YOUR FINGERS.
- 4) USING THE SPECIAL "SUPER GREASE™" INCLUDED IN THE KIT, APPLY GREASE TO THE INSIDE OF THE NEW PROTHANE™ BUSHINGS .
- 5) INSTALL THE NEW PROTHANE™ BUSHINGS SMALLER END FIRST INTO THE CABLE ENDS MAKING SURE THE LARGER END IS FACING AWAY FROM THE SHIFTER OR TRANSMISSION
- 6) PULL THE NEW PROTHANE™ BUSHING AND CABLE BACK INTO ORIGINAL POSITION ON THE PIN.

PARTS LIST FOR KIT #4-1605		
<u>PART#</u>	<u>DESCRIPTION</u>	<u>QTY</u>
U-69167	SHIFTER BUSH. SMALL	3
U-69168	SHIFTER BUSH. LARGE	1
19-1750-001	SUPERGREASE™	1

PARTS LIST FOR KIT #4-1606		
<u>PART#</u>	<u>DESCRIPTION</u>	<u>QTY</u>
U-69167	SHIFTER BUSH. SMALL	4
19-1750-001	SUPERGREASE™	1

FORM 4-1605

INSTALLATION INSTRUCTIONS FOR KITS #4-1605 & #4-1606 NEON & SRT-4 SHIFTER BUSHING KITS

PROTHANE™ RECOMMENDS THAT THIS KIT BE INSTALLED BY A QUALIFIED AUTOMOTIVE TECHNICIAN

- 1) REMOVE THE CONSOLE SURROUNDING THE SHIFTER.
- 2) GENTLY PRY THE CABLE ENDS OFF OF THE SHIFTER-TRANSMISSION LEVERS.
- 3) REMOVE THE FACTORY BUSHINGS BY PUSHING THEM OUT OF THE TOP WITH A SCREWDRIVER OR YOUR FINGERS.
- 4) USING THE SPECIAL "SUPER GREASE™" INCLUDED IN THE KIT, APPLY GREASE TO THE INSIDE OF THE NEW PROTHANE™ BUSHINGS .
- 5) INSTALL THE NEW PROTHANE™ BUSHINGS SMALLER END FIRST INTO THE CABLE ENDS MAKING SURE THE LARGER END IS FACING AWAY FROM THE SHIFTER OR TRANSMISSION
- 6) PULL THE NEW PROTHANE™ BUSHING AND CABLE BACK INTO ORIGINAL POSITION ON THE PIN.

PARTS LIST FOR KIT #4-1605		
<u>PART#</u>	<u>DESCRIPTION</u>	<u>QTY</u>
U-69167	SHIFTER BUSH. SMALL	3
U-69168	SHIFTER BUSH. LARGE	1
19-1750-001	SUPERGREASE™	1

PARTS LIST FOR KIT #4-1606		
<u>PART#</u>	<u>DESCRIPTION</u>	<u>QTY</u>
U-69167	SHIFTER BUSH. SMALL	4
19-1750-001	SUPERGREASE™	1

FORM 4-1605

INSTALLATION INSTRUCTIONS FOR KITS #4-1605 & #4-1606 NEON & SRT-4 SHIFTER BUSHING KITS

PROTHANE™ RECOMMENDS THAT THIS KIT BE INSTALLED BY A QUALIFIED AUTOMOTIVE TECHNICIAN

- 1) REMOVE THE CONSOLE SURROUNDING THE SHIFTER.
- 2) GENTLY PRY THE CABLE ENDS OFF OF THE SHIFTER-TRANSMISSION LEVERS.
- 3) REMOVE THE FACTORY BUSHINGS BY PUSHING THEM OUT OF THE TOP WITH A SCREWDRIVER OR YOUR FINGERS.
- 4) USING THE SPECIAL "SUPER GREASE™" INCLUDED IN THE KIT, APPLY GREASE TO THE INSIDE OF THE NEW PROTHANE™ BUSHINGS .
- 5) INSTALL THE NEW PROTHANE™ BUSHINGS SMALLER END FIRST INTO THE CABLE ENDS MAKING SURE THE LARGER END IS FACING AWAY FROM THE SHIFTER OR TRANSMISSION
- 6) PULL THE NEW PROTHANE™ BUSHING AND CABLE BACK INTO ORIGINAL POSITION ON THE PIN.

PARTS LIST FOR KIT #4-1605		
<u>PART#</u>	<u>DESCRIPTION</u>	<u>QTY</u>
U-69167	SHIFTER BUSH. SMALL	3
U-69168	SHIFTER BUSH. LARGE	1
19-1750-001	SUPERGREASE™	1

PARTS LIST FOR KIT #4-1606		
<u>PART#</u>	<u>DESCRIPTION</u>	<u>QTY</u>
U-69167	SHIFTER BUSH. SMALL	4
19-1750-001	SUPERGREASE™	1

FORM 4-1605
