

INSTALLATION INSTRUCTIONS FOR KIT #4-301 95-99 NEON REAR CONTROL ARM BUSHINGS

-) MARK THE POSITION OF THE ECCENTRIC ADJUSTER ON THE REAR ADJUSTABLE CONTROL ARMS.
-) REMOVE THE REAR CONTROL ARMS FROM THE VEHICLE AS PER THE MANUFACTURER'S SHOP MANUAL. THIS WILL HELP MAINTAIN THE ORIGINAL ALIGNMENT SETTINGS.
-) REMOVE THE RUBBER BUSHINGS FROM THE END OF THE CONTROL ARMS BY FIRST PRESSING OUT THE INNER STEEL SLEEVE AND THEN THE BUSHING. BE CAREFUL NOT TO SCRATCH THE INSIDE OF THE EYELET OR DAMAGE THE INNER SLEEVE IF IT HAS TO BE REUSED (SEE DIAGRAM BELOW).
-) CLEAN INSIDE OF EYELETS. IF NECESSARY SMOOTH OUT ANY ROUGH AREAS WITH SAND PAPER OR EMERY CLOTH.
-) LIGHTLY GREASE THE INSIDE OF EYELETS AND OUTSIDE OF PROTHANE™ BUSHINGS AND HAND PRESS BUSHINGS INTO EYELETS. NEXT LIGHTLY GREASE INSIDE OF THE BUSHINGS AND OUTSIDE OF INNER STEEL SLEEVES AND PRESS INTO BUSHINGS.
-) REINSTALL THE CONTROL ARMS ONTO THE VEHICLE AS PER THE MANUFACTURER'S SHOP MANUAL.
-) ALIGN REAR OF VEHICLE.

PARTS LIST FOR #4-301		
PART #	DESCRIPTION	QTY
U-64214	REAR C-ARM BUSHING (SMALL)	12
U-64215	REAR C-ARM BUSHING (LARGE)	4
SLV-60806	11/16"OD X 1.580"L STEEL SLEEVE	6
WASH-1121	1 1/16"OD X 1/2"ID WASHER	6
WASH-1187	1 1/4"OD X 1/2"ID WASHER	2
19-1750-001	SUPER GREASE	4

