


INSTALLATION INSTRUCTIONS FOR PONTIAC GTO

WARNING: PROTHANE RECOMMENDS THIS AND ALL OF OUR POLYURETHANE SUSPENSION KITS BE INSTALLED BY A QUALIFIED TECHNICIAN.

Kit #7-235

- 1) Remove the front Control Arm from the vehicle.
- 2) Remove the rubber bushing from the control arm. This can be accomplished by burning the bushing out using a propane or acetylene torch. The bushing **shell must be left in the arm** or the new bushing will not fit.
- 3) Once the bushing is burned out then thoroughly clean the inside of the arm.
- 4) Using the grease provided, thoroughly coat bushing #64337 and install into the arm as shown in the diagram.
- 5) Now grease and install the new steel sleeve provided into the bushing.
- 6) Grease the new thrust washer #64338 and install over the end of the sleeve as shown in the diagram.
- 7) Grease the outer face of both bushings and install arm back onto vehicle per manufacturer's directions.



PARTS LIST FOR KIT #7-235

Part #	Description	Qty
U-64337	Bushing	2
U-64338	Thrust Washer	2
SLV-60673	3/4x12mmx2.40"	2
19-1750-001	Super Grease	2

PARTS LIST FOR KIT #7-1212

Part #	Description	Qty
U-65051	Bushing	4
SLV-60935	1.0x1.85" Sleeve	2
19-1760-001	Super Grease	2

Kit #7-1212

- 1) Remove the front Control Arm from the vehicle.
- 2) Remove the rubber strut bushing from the control arm. This can be accomplished by pressing the bushing out using a hydraulic or arbor press.
- 3) Using the grease provided, thoroughly coat bushings #65051 and install into the arm as shown in the diagram.
- 5) Now grease and install the new steel sleeve provided into the bushing. The large end goes toward the rear of the vehicle.
- 6) Place the O.E. concave washer on the strut rod and install the strut rod thru the new bushing.
- 7) Place the O.E. flat washer and nut over the end of the strut rod and tighten to 100lb/ft.
- 8) Reinstall arm per manufacturer's directions.

PROTHANE
MOTION CONTROL