

INSTALLATION INSTRUCTIONS FOR KITS #8-306, 8-307, 8-308, 8-309, 8-904, 8-311, 8-312, 8-313, 8-317

CONTROL ARM, COMPENSATOR ARM & SHOCK BUSHINGS WITH OUTER SLEEVES

- 1) Remove the control or compensator arm from the vehicle.
- 2) Before proceeding any further measure the distance "A" of the original bushing as shown in figure 1.
Record this measurement as it will be critical when installing the new bushing.
- 3) Press out the rubber bushing and outer metal casing from the arm.
- 4) Disassemble the Prothane™ polyurethane bushings.
- 5) Press in the new outer steel sleeve to the previously measured distance "A".
- 6) Grease the inside diameter of the new outer steel sleeve.
- 7) Hand press in the Prothane™ polyurethane bushings into the new outer steel sleeve.
- 8) Grease the inside diameter of the polyurethane bushing and hand press the new inner steel sleeve into the polyurethane bushing.
- 9) The control or compensator arm is now ready to be reinstalled onto the vehicle.




Fig. 1, Side view of control or compensator arm

PARTS LIST FOR KIT # 8-306

PART #	DESCRIPTION	QUANTITY
U-64176	UP/IN C-ARM BUSH	2
U-64176	UP/OUT C-ARM BUSH W/SHAFT	2
U-64181	RR LWR C-ARM BUSH	4
19-1750-001	SUPER GREASE	2

PARTS LIST FOR KIT # 8-307

PART #	DESCRIPTION	QUANTITY
U-64176	UP/IN C-ARM BUSH	2
U-64176	UP/OUT C-ARM BUSH W/SHAFT	2
19-1750-001	SUPER GREASE	1

PARTS LIST FOR KIT # 8-308

PART #	DESCRIPTION	QUANTITY
U-64181	RR LWR C-ARM BUSH	4
19-1750-001	SUPER GREASE	1

PARTS LIST FOR KIT # 8-309

PART #	DESCRIPTION	QUANTITY
U-64177	COMPENSATOR ARM BUSH	4
19-1750-001	SUPER GREASE	1

PARTS LIST FOR KIT # 8-317

PART #	DESCRIPTION	QUANTITY
U-64278	RR WATTS LINK BUSH	4
19-1750-001	SUPER GREASE	1

PARTS LIST FOR KIT # 8-904

PART #	DESCRIPTION	QUANTITY
U-66041	RR LWR SHOCK BUSH	2
U-66033	UPPER SHOCK BUSH	4
19-1750-001	SUPER GREASE	1

PARTS LIST FOR KIT # 8-311

PART #	DESCRIPTION	QUANTITY
U-64207	UPPR C-ARM BUSH W/SHAFT	2
19-1750-001	SUPER GREASE	1

PARTS LIST FOR KIT # 8-312

PART #	DESCRIPTION	QUANTITY
U-64206	LWR C-ARM BUSH	8
19-1750-001	SUPER GREASE	2

PARTS LIST FOR KIT # 8-313

PART #	DESCRIPTION	QUANTITY
U-64206	LWR C-ARM BUSH	8
U-64207	UPPR C-ARM BUSH W/SHAFT	2
19-1750-001	SUPER GREASE	2